



Model	A1	A2	X1	X2	Y1	Y2	B1	B2	H1	H2
<i>KDD-B 80Lx80R</i>	800	800	780-790	780-790	768-778	768-778	383	383	1970	1950
<i>KDD-B 80Lx90R</i>	800	900	780-790	880-890	768-778	868-878	383	433	1970	1950
<i>KDD-B 80Lx100R</i>	800	1000	780-790	980-990	768-778	968-978	383	483	1970	1950
<i>KDD-B 90Lx80R</i>	900	800	880-890	780-790	868-878	768-778	433	383	1970	1950
<i>KDD-B 90Lx90R</i>	900	900	880-890	880-890	868-878	868-878	433	433	1970	1950
<i>KDD-B 90Lx100R</i>	900	1000	880-890	980-990	868-878	968-978	433	483	1970	1950
<i>KDD-B 100Lx80R</i>	1000	800	980-990	780-790	968-978	768-778	483	383	1970	1950
<i>KDD-B 100Lx90R</i>	1000	900	980-990	880-890	968-978	868-878	483	433	1970	1950
<i>KDD-B 100Lx100R</i>	1000	1000	980-990	980-990	968-978	968-978	483	483	1970	1950

